

SWISS ARMY LAMBDA DEVICE

Measure Twice, Cut Once

The following device is required for TH2010



- ❶ 90° Elbow Fitting
- ❷ Tee Fitting
- ❸ 2" PVC section
- ❹ 3 ½" PVC section
- ❺ 17" PVC section
- ❻ 18" PVC section

NOTE 1: All items Schedule 40, ½" PVC

NOTE 2: Pressure Fit All Fittings. Do not glue

NOTE 3: Drill ¼ hole through both sides of PVC

NOTE 4: Scribe 25 marks. ½ inch separation.
Optional: Label each inch marking

