



# HINTS WISE OR OTHERWISE

How do you assemble a Lambda device?

- ① 24" PVC section
- ② Straight Connector Fitting
- ③ 12" PVC section
- ④ Acoustic Cone (optional)
- ⑤ Water Resistant Tape
- ⑥ Foldable Top Sandwich bag
- ⑦ One Rubber Band

**Note 1:** All items 3/4" PVC

**Note 2:** Do not glue

**Note 3:** With a sharpie, draw a 5 point star (approx 0.25" in diameter)


When not in use, keep this section dry

**Note 4:** Place one sandwich bag taught over opening  
Secure tightly with a rubber band

Best performance is achieved when in direct contact

**Note 5:** Cut out cone using template on Page 2  
Secure cone to PVC with tape

Optional attachment, but may improve performance



@THUNTERPHX

WWW.PHOENIXTREASUREHUNT.ORG






# HINTS WISE OR OTHERWISE

## Lambda cone assembly template

- 1) Use water resistant material (transparency, glossy photo paper)
- 2) Cut along solid lines
- 3) Overlap edges to dotted line
- 4) Secure inside & outside seams with tape



@THUNTERPHX

WWW.PHOENIXTREASUREHUNT.ORG

